



**Technical Service
Information Bulletin**

March 30, 2007

Title:

**POWER SYSTEM INITIALIZATION
DURING PDS**

Models:

'07 All Lexus Models

**PRE-DELIVERY SERVICE
PD007-07**

Introduction The following is a list of the vehicle systems (Power Window, Sliding Roof, Tire Pressure Warning System [TPWS], etc.) that need initialization during Pre-Delivery Service (PDS) and the TSIB numbers containing details on initializing each specific system.

NOTE:
Items in **RED** also need to be initialized any time the battery has been disconnected.

- Applicable Vehicles**
- All **2007** model year **Lexus** vehicles.

**Power System
Initialization
Table**

MODEL NAME	INITIALIZATION SYSTEM ITEMS							
	COMPASS	POWER WINDOW	POWER BACK DOOR	SLIDING ROOF	DIRECT TPWS	VGRS	PARKING ASSIST	SEAT
ES 350	PD020-06	-	-	-	PD024-06	-	-	-
GS 350/430	PD045-06	PD044-06	-	-	PD041-06	PD052-06*	PD046-06	PD051-06
GS 450h	PD014-06	PD012-06	-	PD013-06	PD016-06	PD025-06	PD023-06	PD015-06
GX 470	PD058-06	PD050-06	-	PD049-06	PD059-06	-	-	-
IS 250/350	PD031-06	PD030-06	-	-	PD039-06	-	-	-
LS 460	PD067-06	-	-	-	PD072-06	PD071-06	PD068-06	PD075-06
LX 470	PD038-06	-	-	-	PD040-06	PD065-06	-	-
RX 350	PD004-06	PD008-06	PD006-06	PD007-06	PD003-06	-	-	-
RX 400h	PD055-06	PD054-06	PD056-06	-	PD063-06	-	-	-
SC 430	PD037-06	-	-	-	PD064-06	-	-	PD036-06

* Initialization of VGRS applies ONLY to 2007 model year GS 430 vehicles.

**Warranty
Information**

OP CODE	DESCRIPTION	TIME	OFF	T1	T2
N/A	Not Applicable to Warranty	-	-	-	-

