


# Removal of Front Wheel Opening Extension Pad Protective Covers

**Service Category** General

**Section** Pre-Delivery Service

**Market** USA

Lexus Supports ASE Certification 

## Applicability


YEAR(S)	MODEL(S)	ADDITIONAL INFORMATION
2009	LS460	

## Introduction

Protective covers are installed on the front wheel opening extension pads to prevent damage during transit.

Use the following procedure to remove the protective covers during Pre-Delivery Service (PDS).

**Figure 1.**



<b>1</b>	<b>Front Wheel Opening Extension Pad Protective Covers</b>
----------	--

## Warranty Information

OP CODE	DESCRIPTION	TIME	OFP	T1	T2
N/A	Not Applicable to Warranty	—	—	—	—

## Removal Procedure

Remove the protective covers from the front wheel opening extension pads by slowly pulling the cover from one side.

Be sure to completely remove the covers and any tape residue.